

Environmental Monitoring

Independence Solution



What is it?

The Tunstall Vi+, Personal Emergency Response Systems, can monitor a subscribers environment for smoke or for extreme changes in temperature. All Environmental Solutions result in alerting a caregiver and if necessary emergency responders.

Smoke Detection

What is it?

The Tunstall Smoke Detector works with the Vi+ home monitoring units. The Smoke Detector audibly warns the subscriber of possible danger.

How does it work?

By simply pairing the smoke detector(s) with the subscribers Vi+ unit, it will automatically make a call to the Emergency Response Center (ERC) if smoke is detected.

Extreme Temperature Monitoring

What is it?

The Vi+ unit can monitor the environmental temperature and will report to the ERC when the room temperature rises above 89°F or falls below 50°F. Monitoring the subscribers environment for unhealthy temperature that could pose a risk to the subscriber.



How does it work?

The Tunstall Vi+ has an integral ambient temperature sensor built into the unit. The Vi+ will monitor the environmental temperature and will signal the ERC when the room temperature rises above 89 or falls below 50 and will notify a family member or caregiver of the situation.

Who is it for?

Anyone could benefit from these solutions, but particularly seniors living alone and people with memory problems who need some extra support.

Environmental Monitoring

Independence Solution

Smoke Detector Specifications

• Part(s) for this solution	• Smoke Detector (64604/15) Vi+(57104/570)
• Dimensions	• 4.7" x 1.8" (W x L)
• Weight	• 0.46lbs
• Battery	• 2 years, 9V Alkaline (replaceable)
• Installation Requirements	• Surface mounted on ceiling or wall using two screws. Detector programmed to base console
• Options	• Periodic testing Periodic battery change
• Maintenance Requirements	• None

Extreme Temperature Monitoring Specifications

• Part(s) for this solution	• Vi+(57104/570)
• Dimensions	• N/A
• Weight	• N/A
• Battery	• N/A
• Installation Requirements	• Local or remote configuration of the feature
• Options	• High and Low temperature alerts can be sent to the ERC or to a caregiver directly
• Maintenance Requirements	• None

For additional information please call
1.800.728.3775
or info@saversalert.com
www.saversalert.com

